

Burg Wachter Point Safes - Master Code Retrieval Procedures (2 pages)

Submitted by **John W Soderland, CML,CMST** (414) 327-5625

Burg Wachter Point Safe (P1E old style) Master Code Retrieval Procedure

Open safe.

With door open, extend boltwork with key or combo.

(If neither is available, extend boltwork manually after panel is removed in steps listed below)

Remove batteries.

Remove two screws from door panel.

Remove door panel, set aside, being careful not to pull on wiring.

Locate jumper near upper left hand corner of circuit board.

Note jumper is installed on only one pin.

Carefully trim silicone sealant from jumper to allow removal of jumper.

Place jumper over two exposed pins.

Install batteries, observing polarity.

Press "enter" key.

One long tone, and one short tone will be heard.

Remove jumper, and discard or place over only one pin (for storage).

Press:"1,2,3,4,5,6,7,8,enter"

Press:"1,2,3,4,5,6,7,8,enter" again to confirm.

Wait 20 seconds, door will unlock.

Press:"enter,1,6,8,enter.

Remove batteries, reinstall door panel, reinstall batteries.

Master code has been restored to default of: 1,2,3,4,5,6,7,8.

User code has been restored to default of: 1,6,8

**Burg Wachter Point Safes (P2E, P3E, P4E) (and new style P1E)
Master Code Retrieval Procedure**

**Master Code Retrieval Procedure
Submitted by John W. Soderland, CML,CMST
(414)327-5625**

These units can be identified by the inner door panel being held on by three or more screws, the keypad is on the left side of the key override, and "P2E" is printed on the circuit board.

Open safe.

With door open, extend boltwork with user combo or key.

Remove batteries.

Remove screws from door panel.

Remove door panel, set aside, being careful not to pull on wiring.

Locate jumper near top center of circuit board, above main IC chip.

Note jumper is installed on two lefthand pins.

Carefully trim silicone sealant from jumper to allow removal of jumper.

Place jumper over two righthand pins.

Install batteries, observing polarity.

Single beep will be heard.

Press "1,2,3,4,5,6,7,8,enter"

Press "1,2,3,4,5,6,7,8,enter" again to confirm

Wait 20 seconds, door will unlock. Remove batteries.

Remove jumper from two righthand pins, and reinstall over two lefthand pins. Install door panel

Install Batteries, again observing polarity.

Press:"enter" if boltwork does not extend, press "1,6,8,enter"

If boltwork extends during step listed above,

Press:"enter,8,8,8,8,8,8,8,8,enter. Boltwork will retract.

Press:"enter,1,6,8,enter"

Master code has been restored to default of:1,2,3,4,5,6,7,8.

User code has been restored to "1,6,8.