

# Strongarm Mini Rig Templates

## Strongarm

### #1

S&G 6730, 8400, 8500:

Fence	A
Lever Screw	B
Relocker	D
Mounting Screw	E
Scope	G (T2)

LaGard 1800, 1980, 3330

Fence	A
Relocker (1800, 1980)	C
Relocker (3330)	C1

Diebold 177,180, 900

Fence	A
Mounting Screw	E

Kaba Mas (X-07):

Lever Screw	B
-------------	---

### #2

S&G 6730, 8400, 8500:

Scope	G
-------	---

Mosler 120:

Lever Post	I
Scope	F
Relocker	K

### #2

Mosler 302:

Fence	G
Scope	H
Relocker	J
Mounting Screw	L

### #3

LaGard Old Style 3600, 99E, 99E:

Relocker	M
Sidebar (33E)	N
Solenoid (3600)	O
Solenoid (33E, 99E)	P
Solenoid (3600 LH)	V

### #4

Mas Hamilton X-07:

Fence Pin	Q
Relocker	R
Lever Screw	S
Magnetic Relock	T
Step Motor	U

### T4

Kaba Mas X-07, Auditcon  
Cencon, Slidebolt:

Fence Pin (X-07, Auditcon Cencon, Slidebolt)	R
Relocker (X-07, X-08, X-09, Old Auditcon & Cencon)	S
Relocker (New Auditcon & Cencon)	SS
Gear (X-08)	U
Slide (X-08, X-09)	UU

## T4

### Kaba Mas B-52 Slide Bolt:

#### Solenoid Pin:

RH – Bolt Slides Up	TT
RH – Bolt Slides Down	T
LH – Bolt Slides Up	T
LH- Bolt Slides Down	TT
VU – Bolt Slides to Right	TT
VU – Bolt Slides To Left	T
VD – Bolt Slides To Right	T
VD – Bolt Slides To Left	TT

#### Push Back Of Solenoid Button:

See T7

## T5

### Major Round Door:

Transfer to Fence Drop In	Y
---------------------------	---

### Gary Round Door:

Transfer To Fence Drop In	X
---------------------------	---

### Star:

Fence	W
-------	---

## T7

### Mosler 302:

Scope Hole	A2
------------	----

### LaGard:

New ComboGard	B2
---------------	----

## T7

### Kaba Mas B-52:

#### Push Back Of Solenoid Button:

RH – Bolt Slides Up	D2
RH – Bolt Slides Down	DD2
LH – Bolt Slides Up	DD2
LH- Bolt Slides Down	D2
VU – Bolt Slides to Right	D2
VU – Bolt Slides To Left	DD2
VD – Bolt Slides To Right	DD2
VD – Bolt Slides To Left	D2

### AMSEC:

ESL 10/20	C2
-----------	----

### S&G 6120, 6123:

Armature	Spindle Hole
Relocker	E2
Deadlatch	E3