

## Chrysler 7/8-cut (Y-160) Tryout Keys Glove Box Set

Cuts made in locations 5 through 8, 0.677", 0.769", 0.861", 0.953"

Tip stop key in cutter, use Framon block #3, first cut is at 0.308"

Cut #0 = 0.327    Cut #1 = 0.277

0000	Key #1	Once you determine which side of the tryout is working in the glovebox or storage compartment, make your cuts either #1 or #3 depths and fit by impressing the above to final fit, and go to the trunk or door for the first three cuts, or on an 8-cut, cuts 2 through 4, and progress your first cut in the ignition.		
0001				
0010	Key #2			
0011				
0100	Key #3			
0101				
0110	Key #4	The trunk or door cuts can also be progressed as follows:		
0111				
1001	Key #5	1 <sup>st</sup> Key	2 <sup>nd</sup> Key	3 <sup>rd</sup> Key
1000		111	131	311
1010	Key #6	113	331	313
1011		133		
		333		
1100	Key #7			
1101				
1110	Key #8			
1111				