



How-Do-We-Do-That?

Ford & Mazda Tire locks

You can use a Club blank form ILCO # 1573A and use it as a spare key.

The following are codes. The number can be found on the lock itself.

It is recommended to file the number off the lock after marking it at a safe place.

Arnold

F001	23231	F002	31311
F003	31323	F004	12121
F005	32121	F006	33211
F007	23133	F008	21213
F009	23121	F010	31211
F011	23211	F012	13231
F013	12321	F014	32311
F015	12131	F016	31321
F017	13112	F018	23131
F019	12313	F020	21313
F021	13213	F022	21323
F023	31313	F024	12311
F025	23123		

Spacing's are;

1 .118 2 .213 3 .307 4 .402 5 .596

Depths are;

1 .283 2 .256 3 .228

