

HOW TO PICK U-CHANGE LOCKS

- Step
1. Put key in key slot.
 2. Put a wire (30,000 wire, or Gauge #12 music wire) in the change tool slot.
 3. Remove the key from the key slot.
 4. Place tension bar tool in the key slot and put pressure on the cylinder while using the curve pick to rake across the tumblers.
 5. All five tumblers should drop down. When all have dropped, the cylinder will turn.
 6. Stop the cylinder at the 90 degree change position.
 7. Remove the wire from the change tool slot.
 8. Insert change tool and the key you want the lock keyed to. This may be done by alternating insertion of the key and change tool.
 9. Take out the change tool and lock will be set to the key.

*NOTE: If the key will not go into the key slot (Step 1), tech can shim the cylinder from the front by picking each sub or if the cylinder can be removed, then he can shim it from the rear.

*NOTE: If lubrication is needed, we recommend WD-40. Do not use a lubricant that has graphite in it. This will void the warranty!