

Wind/Danbury Codes

W601 33232	W611 23312	W621 23112	W631 12332	W641 31122
W602 31311	W612 33313	W622 13113	W632 23323	W642 12123
W603 13131	W613 13221	W623 12323	W633 21231	W643 21321
W604 22133	W614 11232	W624 33212	W634 33133	W644 33223
W605 33111	W615 23321	W625 12121	W635 11212	W645 31131
W606 22113	W616 21332	W626 21123	W636 33113	W646 32332
W607 11311	W617 32323	W627 33221	W637 22311	W647 13212
W608 11133	W618 33131	W628 31232	W638 21312	W648 12231
W609 32213	W619 13133	W629 13223	W639 -----	W649 21233
W610 21121	W620 21211	W630 11131	W640 32121	W650 32211

Cutting Specs

Shoulder to first cut - .120"

Spacing between cuts - .100"

Spacing: 120 - 220 - 320 - 420 - 520

Keyblank: Y13 / O1122R

Depths: #1 - .240 #2 - .220 #3 - .200

You will have to cut the #1 cut - blank is .250"

Wind/Danbury Master Key - 12321 cut on IL260 blank

Wind/Danbury Removal Key - 123212 cut on IL260 blank

Cut top and bottom shoulders back .125 Spacing is 120-220-320-420-520-620