



# How-Do-We-Do-That?

A customer needed the combination changed on a Sunar lock. He did not want to use the same key as before. The code number on this lock was available.



To remove the cylinder plug from this lock, insert your lock pick and push retainer pin upward and at the same time pull on the cylinder plug.



Remove cylinder cap and place bottom pins in a different order and make the keys.

Arnold

After cutting the key to code I found that this lock must have been changed before.

